

NOTES:

- 1. Circuits subject to change without notice
- 2. The neutral wire(White or Gray wire) must be connected to the prescribed
- tab terminal of the lamp socket.
- 3. Only certain models use the humidity sensor.
- 4. The neutral wire(White/Gray wire) must be connected to the winding start tab terminal of the power transformer primary winding.