PRODUCT MODEL NUMBERS


RCS2002L RCS3004L RCS2012L RCS3014L RCS3614L

Electrical:

240-volt cooktop: A three-wire or four-wire, single phase, 240-volt, 60-Hz, AC-only electrical supply is required on a separate, 40-ampere circuit (note: the RCS2012 series requires a 20 ampere circuit), fused on both sides of the line. Use copper wire only. A time-delay fuse or circuit breaker is recommended.

120-volt cooktop:120-volt, 60-Hz, AC-only, 20-amp. electrical supply. Use copper wire only. A time-delay fuse or circuit breaker and separate circuit is recommended.

OVERALL DIMENSIONS



CABINET OPENING DIMENSIONS

