CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING







DETAIL FOR SPRAY SUBINTERVAL AND PAUSE FOR MOTOR TO PUMP CONTROL CIRCUITS.



TIMER PLUG-MALE (END VIEW)







NOTE:
SUFFIX INDICATES TIMER SWITCH CONTACTS
T= TOP
B= BOTTOM

WIRING DIAGRAM
P/N 131999800