


CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING

TERM.	REGULAR		OFF		PERM. PRESS		OFF		DELICATE		OFF				
	WASH (16 MIN)	PUMP (6 MIN)	RINSE (4 MIN)	PUMP (10 MIN)	SPIN	WASH (12 MIN)	PUMP (6 MIN)	RINSE (4 MIN)	PUMP (6 MIN)	SPIN		WASH (8 MIN)	PUMP (6 MIN)	RINSE (4 MIN)	PUMP (6 MIN)
0	2														
2	5														
3	3														
4	20														
6	11														
8	14														
10	17														
12	20														
14	20														



NOTE: SUFFIX INDICATES TIMER SWITCH CONTACTS
T= TOP
B= BOTTOM

○=OPEN X=CLOSED
(OPT)=OPTIONAL ON SOME MODELS