# hirlpool<sup>®</sup> Electric Built-in Cooktop

## PRODUCT MODEL NUMBERS

#### RCS2002G RCS2012G RCS3004G


RCS3014G RCS3614G

### Electrical:

**240-volt cooktop:** A three-wire or four-wire, single phase, 240-volt, 60-Hz, AC-only electrical supply is required on a separate, 40-ampere circuit (note: the RCS2012 series requires a 20 ampere circuit), fused on both sides of the line. A time-delay fuse or circuit breaker is recommended. The fuse size must not exceed the circuit rating of the appliance specified on the model/serial rating plate located on the bottom of the cooktop.

**120-volt cooktop:** A 120-volt, 60-Hz, AC-only, 20-ampere, fused electrical supply is required. (Time-delay fuse or circuit breaker is recommended.) It is recommended that a separate circuit serving only this appliance be provided. A NEMA 5-20R, 3-prong ground-type outlet must be used.

#### OVERALL DIMENSIONS




#### CABINET OPENING DIMENSIONS

	Illustration dimensions		
Cooktop width	۵	0	Θ
21"	18-5/8"	15-1/2"	21"
(53.3 cm)	(33.7 cm)	(34.4 cm)	(53.3 cm)
30"	28-7/8"	18-5/8"	30"
(76.2 cm)	(73.3 cm)	(47.3 cm)	(76.2 cm)
36"	35"	18-5/8"	36"
(91.4 cm)	(89 cm)	(47.3 cm)	(91.4 cm)

Important note on base cabinet construction: After making the countertop cutout, some installations may require notching down the base cabinet side walls to clear the burner box. To avoid this modification, use a base cabinet having sidewalls wider the the cutout.

**Note:** If cabinet has a drawer, a 4" (10.2 cm) depth clearance from the countertop to the top of the drawer (or other obstruction) in base cabinet is required.



Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice. Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.